



COACH MODEL : C2045

DATE: 08-31-2011

SUBJECT : Batteries and current distribution location

Battery door RHS in front of drive tires





Manual Battery Disconnect



Batteries on slide tray




Chassis Grounds









1. Master Switch Relay 24V

2. Alternator 1 & 2 Z08 & Z09 (200 amps fuse)