

LEFT CONSOLE PANEL & DOOR CONTROLS

- 1 Driver's Speaker
- 2 Cup Holders
- 3 Parking Brake Control
- 4 Mirror Adjusting Switch
- 5 Microphone Socket
- 6 12V Socket
- **7** Emergency Cut-Off Switch
- 8 Blank
- Parking Brake Emergency Release Knob

DOOR CONTROLS

- 1 Entrance Door Override
- Control Valve 2 Entrance Door
- Emergency Release 3 HVAC Air Vent



CX45 INTERIOR WHEELCHAIR LIFT

COMPARTMENT

2 Threshold Warning System

5 Lift Door Emergency Handle

3 Lift Door Emergency Air Release Knob

1 Lift Lighting

Module

4 Belt Cutter

CONTROL PANEL IN ENGINE COMPARTMENT

- "Stationary Regeneration Request" Button
 "Regeneration Inhibited" Button
 Start Engine Button
 Stop Engine Button
 Socket For Portable Lamp
 Engine Compartment Lights
- 7 Starting Interlock Switch



CX35 INTERIOR WHEELCHAIR LIFT COMPARTMENT

- 1 Lift Lighting
- 2 Lift Door Emergency Air Release Knob
- 3 Belt Cutter
- 4 Lift Door Emergency Handle

WHEELCHAIR LIFT







CONTROL PENDANT

1 Up 2 Down

3 Stow4 Deploy

ABC CUSTOMERCARE SERVICE 24/7

ABC CustomerCare Van Hool Technical Support

Emergency Roadside Assistance

Toll-free 877-427-7278

www.abc-companies.com/pages/directory_customer_care

www.abc-companies.com



VAN HOOL CX35 & CX45 DRIVER'S GUIDE

CX45: VIN# 48469 – ... CX35: VIN# 48775 – ...





CX35 & CX45 DRIVER'S GUIDE

LEFT HAND **DASHBOARD**

- 1 Master Ignition
- 2 Starter
- 3 Defroster Vent
- 4 Emissions Fault Light Indicator (Cummins Only)
- 5 Transmission Shift Pad



COMBINATION SWITCH ON **STEERING COLUMN**

- **1** Turn Signal, High/Low Beam Lever
- 2 Windshield Washer
- 3 Horn
- 4 Windshield Wiper Control



DRIVER'S FLOORBOARD AREA

Press Brake Pedal BEFORE Selecting Gear

R

N

D

202-F0

MODE

4

₹

Q

1 Steering Column Adjustment



CENTER INSTRUMENT PANEL

 Parking Brake Applied Indicator (Red) 2 High Beam Activated (Blue) 3 Turn Signals Activated (Green) (4) Serious Fault Light (Red) 5 Minor Fault Light (Yellow) 6 Not Used 7 Not Used Passenger/Lift Door Open / Low Air Tell-Tale (Red) 8 Speedometer 9 10 Odometer **11** Fuel Gauge **12** Multifunctional Messages Display • Low air pressure gauge 13 Multiplex Function Buttons / Dashboard Lighting Dimmer **14** Outside Temperature 15 Average Mile Per Gallon **16** DEF % Level Gauge 17 Tachometer 18 **Coolant Temperature Gauge**

This guide applies to Van Hool CX models, year 2013 and newer. Effective as of 08/15/2019.

Vehicle specifications subject to change without notice. All information, illustrations, and specifications contained in this guide are based on the latest product information available at the time of production. The right is reserved to make changes at any time without notice. Please refer to all owner, operations, maintenance, or parts manuals and associated documentation for further information.



RIGHT SWITCH PANEL

- Cruise Control
- 2 Cruise Control RES/ACCEL & SET/ COAST
- 3 Engine Fast Idle
- 4 Blank
- 5 Exterior Lighting
- 6 Fog Lamps
- **7** Cornering Lamps
- 8 Docking Lights
- **9** 110V
- **10** Driver's Light
- **11** Reading Lights
- 12 Passenger Compartment Reading Lights
- 13 Blank
- **14** Hazard Warning Signal
- 15 Driver's Fan Speed
- **16** Driver's Temperature Control
- **17** Driver's Fresh Air Control
- 18 Blank
- **19** Main Climate Control System
- 20 Passenger Compartment Climate Control
- 21 Passenger Compartment Fresh Air
- 22 Blank

- 23 Blank
- 24 Blank
- 25 Blank
- 26 Passenger Chime Control
- 27 Wheelchair Power
- 28 Blank
- 29 Driver's L Hand Sun Blind
- 30 Driver's R Hand Sun Blind
- 31 Blank
- 32 Adaptive Cruise Control ON/OFF
- **33** Adaptive Cruise Control Range
- 34 Lane Departure Warning
- **35** Engine Brake
- **36** Engine Override
- 37 Side Mirror Heating/Defroster
- 38 Auxiliary Heater
- **39** Tire Pressure Monitoring Display
- 40 Passenger Door OPEN/CLOSE
- 41 Front Kneeler
- 42 Rear Raise
- 43 Tag Axle Release
- 44 Automatic Slip Reduction (ATC)
- 45 Luggage Compartment Lock
- 46 Passenger Compartment Lighting