




LEFT CONSOLE PANEL & DOOR CONTROLS

- 1 Driver's speaker
- 2 Cup holders
- 3 Parking brake control
- 4 Mirror adjusting switch
- 5 Microphone socket
- 6 12V light socket
- 7 Emergency cut-off switch
- 8 Blank
- 9 Parking brake emergency release knob



- 1 Passenger door override control valve
- 2 Entrance door emergency release
- 3 HVAC air vent



CONTROL PANEL IN ENGINE COMPARTMENT

- 1 "Stationary regeneration request" button
- 2 "Regeneration inhibited" button
- 3 Start engine button
- 4 Stop engine button
- 5 Socket for portable lamp
- 6 Engine compartment lights
- 7 Starting interlock switch

INTERIOR WHEELCHAIR LIFT COMPARTMENT



- 1 Lift lighting
- 2 Threshold warning system module
- 3 Lift door emergency air release knob
- 4 Belt cutter
- 5 Lift door emergency handle



VAN HOOL CX45 DRIVER'S GUIDE

Version One: VIN# 48200 – 48468



WHEELCHAIR LIFT SYSTEM



MANUAL BYPASS KNOBS

- 1 In
- 2 Out
- 3 Up
- 4 Down
- 5 Power switch



CONTROL PENDANT

- 1 Up
- 2 Down
- 3 Stow
- 4 Deploy

ABC CUSTOMERCARE SERVICE 24/7

ABC CustomerCare
Van Hool Technical Support
Emergency Roadside Assistance
Toll-free 877-427-7278
www.abc-companies.com/care.asp



www.abc-companies.com



CX45

DRIVER'S GUIDE

LEFT HAND DASHBOARD PANEL

- 1 Master ignition
- 2 Starter
- 3 Defroster vent
- 4 Transmission shift pad



COMBINATION SWITCH ON STEERING COLUMN

- 1 Turn signal, high/low beam lever
- 2 Windshield washer
- 3 Horn
- 4 Windshield wiper control



DRIVER'S FLOORBOARD AREA

- 1 Steering column adjustment



CENTER INSTRUMENT PANEL

- 1 Parking brake applied indicator (red)
- 2 High beam activated (blue)
- 3 Turn signals activated (green)
- 4 Red serious fault light
- 5 Yellow minor fault light
- 6 Not used
- 7 Not used
- 8 Passenger/lift door low air tell-tale
- 9 Speedometer
- 10 Odometer
- 11 Fuel gauge
- 12 Multifunctional display messages
 - Low air pressure gauge
- 13 Multiplex function buttons
- 14 Outside temperature
- 15 Average mile per gallon
- 16 Tachometer
- 17 Coolant temperature gauge



RIGHT SWITCH PANEL

- 1 Cruise control
- 2 Cruise control RES/ACCEL & SET/COAST
- 3 Fast idle option
- 4 Hazard warning signal
- 5 Exterior lighting
- 6 Fog lamps (option)
- 7 Cornering lamps
- 8 Driver's cab lighting
- 9 Passenger compartment lighting
- 10 120 Volt
- 11 Luggage compartment lighting
- 12 Docking lights
- 13 Driver's left hand sun blind
- 14 Driver's right hand sun blind
- 15 Driver's fan speed control
- 16 Driver's thermostat
- 17 Driver's fresh air control
- 18 Main climate control system
- 19 Passenger compartment thermostat
- 20 Passenger compartment fresh air
- 21 Auxiliary heater
- 22 Exterior mirror heating
- 23 Lane departure warning system
- 24 Lane departure warning display
- 25 Rear raise
- 26 Front kneeler
- 27 Wheelchair lift (option)
- 28 Blank
- 29 Passenger door open/close
- 30 Jake brake
- 31 Automatic Slip Reduction (ATC)
- 32 Blank
- 33 Engine stop override
- 34 Tire monitoring display
- 35 Passenger chime control
- 36 Blank
- 37 Engine fast idle
- 38 Blank
- 39 Blank
- 40 Luggage compartment lock

This guide applies to Van Hool CX models, year 2013 and newer. Effective as of 2/1/15.

Vehicle specifications subject to change without notice. All information, illustrations, and specifications contained in this guide are based on the latest product information available at the time of production. The right is reserved to make changes at any time without notice.

Please refer to all owner, operations, maintenance, or parts manuals and associated documentation for further information.