


EXTERIOR CONTROLS (OUTSIDE OF COACH, RIGHT SIDE)



- 1 Entrance Door Emergency Release
- 2 DEF (Diesel Exhaust Fluid) Filler Opening

WHEELCHAIR ACCESS

- 1 Wheelchair Ramp
- 2 Rear Door Emergency Release
- 3 Lavatory Emergency Door Ley
- 4 Belt Cutter




CONTROL PANEL IN ENGINE COMPARTMENT

- 1 Stop Button
- 2 Start Engine Button
- 3 Starting Interlock Switch
- 4 Engine Compartment Lights
- 5 "Regeneration Inhibited" Button
- 6 "Stationary Regeneration Request" Button

DIAGNOSTIC PLUGS

- 1 Transmission Data Port
- 2 ABS Data Port
- 3 Engine Data Port
- 4 Kibes/Cavtan Data Port



ABC CustomerCare SERVICE 24/7

ABC CustomerCare
Van Hool Technical Support
Emergency Roadside Assistance
Toll-free 877-427-7278
www.abc-companies.com/care.asp



www.abc-companies.com



VANHOOL TD925 DRIVER'S GUIDE

Version Two: VIN# 42768 – end of TD925 models



TD925

DRIVER'S GUIDE

LEFT HAND DASHBOARD PANEL

- 1 Starter
- 2 MIL Light
- 3 Driver's Cab Lighting
- 4 Multiset Lighting
- 5 Passenger Compartment Lighting
- 6 Exterior Lighting
- 7 Blank
- 8 Blank
- 9 Master Ignition
- 10 Backup Battery
- 11 120 Volt
- 12 Lincoln Tunnel
- 13 Raise/Lower From Normal Ride Height
- 14 Front Kneeler
- 15 Tag Axle Unloading System
- 16 Engine Fast Idle
- 17 Emergency Engine Override
- 18 Automatic Slip Reduction (ASR)
- 19 Retarder Foot Switch Disabler
- 20 Transmission Shift Pad




COMBINATION SWITCH ON STEERING COLUMN

- 1 Turn Signal, High/Low Beam Lever
- 2 Windshield Washer
- 3 Horn
- 4 Windshield Wiper Control



LEFT CONSOLE PANEL

- 1 Parking Brake Emergency Release Knob
- 2 AESYS Destination Sign Controller



CENTER INSTRUMENT PANEL

- 1 Parking Brake Applied Indicator (Red)
- 2 High Beam Activated (Blue)
- 3 Turn Signals Activated (Green)
- 4 Red Serious Fault light
- 5 Yellow Minor Fault Light
- 6 Not Used
- 7 Not Used
- 8 Passenger/Lift Door Low Air Tell-Tale
- 9 Speedometer
- 10 Odometer
- 11 Fuel Gauge
- 12 Multifunctional Display
- 13 Multiplex Function Buttons
- 14 Tachometer
- 15 Coolant Temperature Gauge

ENTERTAINMENT / SAUCON TDS / AESYS DESTINATION SIGN (OPTIONAL)



- 1 Entertainment Unit
- 2 Saucan TDS
- 3 Hazard Warning Signal
- 4 Front Passenger Door Open/Close
- 5 Rear Passenger Door Open/Close
- 6 Luggage Compartment Door Open/Close




RIGHT SWITCH PANEL

- 1 Radio Controller
- 2 Entertainment Switch Controller
- 3 Driver's Window Defroster
- 4 Driver's Air Conditioning Fan Speed
- 5 Blank
- 6 Lane Departure Warning Display
- 7 Tire Pressure Monitoring

DOOR CONTROLS (FRONT & REAR)

- 1 Entrance Door Emergency Release
- 2 Manual Door Lock



DRIVER'S FLOORBOARD AREA

- 1 Steering Column Control
- 2 Brake
- 3 Accelerator

This guide applies to Van Hool TD925 models, year 2004 and newer. Effective as of 3/1/15.

Vehicle specifications subject to change without notice. All information, illustrations, and specifications contained in this guide are based on the latest product information available at the time of production. The right is reserved to make changes at any time without notice.

Please refer to all owner, operations, maintenance, or parts manuals and associated documentation for further information.