




LEFT CONSOLE PANEL & DOOR CONTROLS

- 1 Driver's speaker
- 2 Cup holders
- 3 Parking brake control
- 4 Mirror adjusting switch
- 5 Microphone socket
- 6 12V light socket
- 7 Emergency cut-off switch
- 8 Blank
- 9 Parking brake emergency release knob



- 1 Passenger door override control valve
- 2 Entrance door emergency release
- 3 HVAC air vent



CONTROL PANEL IN ENGINE COMPARTMENT

- 1 "Stationary regeneration request" button
- 2 "Regeneration inhibited" button
- 3 Start engine button
- 4 Stop engine button
- 5 Socket for portable lamp
- 6 Engine compartment lights
- 7 Starting interlock switch


CX45 INTERIOR WHEELCHAIR LIFT COMPARTMENT

- 1 Lift lighting
- 2 Threshold warning system module
- 3 Lift door emergency air release knob
- 4 Belt cutter
- 5 Lift door emergency handle



CX35 INTERIOR WHEELCHAIR LIFT COMPARTMENT

- 1 Lift lighting
- 2 Lift door emergency air release knob
- 3 Belt cutter
- 4 Lift door emergency handle



WHEELCHAIR LIFT SYSTEM



MANUAL BYPASS KNOBS

- 1 In
- 2 Out
- 3 Up
- 4 Down
- 5 Power switch



CONTROL PENDANT

- 1 Up
- 2 Down
- 3 Stow
- 4 Deploy



VAN HOOOL

CX35 & CX45

DRIVER'S GUIDE

CX45: VIN# 48469 - ...
CX35: VIN# 48775 - ...



ABC CUSTOMERCARE SERVICE 24/7

ABC CustomerCare
 Van Hool Technical Support
 Emergency Roadside Assistance

Toll-free 877-427-7278

www.abc-companies.com/care.asp

www.abc-companies.com



Exclusive U.S. VAN HOOOL Distributor

CX35 & CX45 DRIVER'S GUIDE

LEFT HAND DASHBOARD PANEL

- 1 Master ignition
- 2 Starter
- 3 Defroster vent
- 4 MIL light indicator
- 5 Transmission shift pad



COMBINATION SWITCH ON STEERING COLUMN

- 1 Turn signal, high/low beam lever
- 2 Windshield washer
- 3 Horn
- 4 Windshield wiper control



DRIVER'S FLOORBOARD AREA

- 1 Steering column adjustment



CENTER INSTRUMENT PANEL

- 1 Parking brake applied indicator (red)
- 2 High beam activated (blue)
- 3 Turn signals activated (green)
- 4 Red serious fault light
- 5 Yellow minor fault light
- 6 Not used
- 7 Not used
- 8 Passenger/lift door low air tell-tale
- 9 Speedometer
- 10 Odometer
- 11 Fuel gauge
- 12 Multifunctional display messages
 - Low air pressure gauge
- 13 Multiplex function buttons
- 14 Outside temperature
- 15 Average mile per gallon
- 16 Tachometer
- 17 Coolant temperature gauge



RIGHT SWITCH PANEL

- | | |
|---|--|
| <ol style="list-style-type: none"> 1 Cruise control 2 Cruise control RES/ACCEL & SET/COAST 3 Engine fast idle 4 Hazard warning signal 5 Exterior lighting 6 Fog lamps (option) 7 Cornering lamps 8 Docking lights 9 120 Volt 10 Driver's cab lighting 11 Passenger compartment lighting 12 Blank 13 Blank 14 Driver's fan speed control 15 Driver's thermostat 16 Driver's fresh air control 17 Blank 18 Main climate control system 19 Passenger compartment thermostat 20 Passenger compartment fresh air 21 Blank 22 Blank 23 Blank | <ol style="list-style-type: none"> 24 Blank 25 Passenger chime control 26 Wheelchair lift (option) 27 Blank 28 Blank 29 Driver's left hand sun blind 30 Driver's right hand sun blind 31 Blank 32 Lane departure warning system 33 Lane departure warning display 34 Jake brake 35 Engine stop override 36 Exterior mirror heating 37 Auxiliary heater 38 Tire monitoring display 39 Passenger door open/close 40 Front kneeler 41 Rear raise 42 Blank 43 Automatic Slip Reduction (ATC) 44 Luggage compartment lock 45 Luggage compartment lighting 46 |
|---|--|

This guide applies to Van Hool CX models, year 2013 and newer. Effective as of 11/1/15.

Vehicle specifications subject to change without notice. All information, illustrations, and specifications contained in this guide are based on the latest product information available at the time of production. The right is reserved to make changes at any time without notice.

Please refer to all owner, operations, maintenance, or parts manuals and associated documentation for further information.

