

Introducing ABC's

Exclusive U.S. VAN TOOL Distributor

Coach Refurbishment Program

Refurbishment Menu for Customer Fleets

List of Options:

- 25 Point Mechanical Inspection
- 50 Point Mechanical Inspection

MECHANICAL

- Rebuilt S 60 Engine w/Accessories, Hoses, & Belts
- Rebuilt Cummins ISM 450 w/Accessories, Hoses, & Belts
- Rebuilt B500 w/New Driveline
- Wheelchair Lift Installation
- Two Color Paint
- New Unitized Wheel Bearings (6)
- New Front Independent Suspension Bushings
- New Tag Axle Independent Bushings
- New Air Bellows
- Drive Axle Upper Stabilizers
- Rebuilt A/C Compressor
- Radiator
- Charged Air Cooler
- New Tires
- New Brake Chambers, Hoses
- Rebuilt Air Dryer
- New Batteries
- Rebuilt 140 Amp Alternators
- New ABC Shock Absorbors
- Nine Inch Steel Wheel Kit
- Nine Inch Durabright Alcoa Wheels

SAFETY

- 3 Point Belt Passenger Seats
- 3 Point Belt Driver Seat
- AVIR Inspection
- Saucon
- Kidde Fire Suppression System
- SmartWave Tire Monitoring System
- Back-up Camera System

BODY

- New Front Cap w/Upgraded Headlight Assembly
- Rear Window Cap
- New LED Side Turn Lights
- New LED Tail Light Package
- New Aisle Floor Covering
- New Step Treads
- Digital Graphics
- New Windshields
- Dash Restoration

PASSENGER AMENITIES

- Wi Fi
- AM-FM DVD
- 110 Volt Power Supply
- AM-FM DVD w/4 (15.4") Monitors

50 Point Checklist

- 1 Engine air intake piping for loose clamps, cracked hoses, etc. (visually)
- 2 Drive belts condition and tension (visually)
- 3 Pipes and hoses for security, damage and chaffing
- 4 Fluid leaks in engine compartment, wheel hubs etc.
- **5** Tire inflation and condition
- **6** Wheel nuts for tightness
- 7 Wheel rims for cracks and deformation
- 8 Suspension ride height
- 9 Emergency windows for security
- 10 Air cleaner restriction indicator
- 11 Crankcase breather tube (Cummins)
- 12 Dashboard gauges and warning lights operation
- 13 Screen in air intake for radiator
- 14 Engine rear mounts adjustment
- 15 Engine coolant DCA
- 16 Engine coolant antifreeze concentration level
- 17 Engine air cleaner restriction indicator operation
- 18 Steering ball-joints for excessive play
- 19 Battery cable connections for corrosion and tightness
- **20** Battery electrolyte level
- 21 General condition of the brake assemblies for damage and corrosion
- 22 Brake lining wear
- 23 Brake chamber condition and leaks
- 24 Brake system valves, lines and fitting for leaks
- 25 Suspension air bellows external condition / leaks
- **26** Shock absorbers for external damage and leakage
- **27** Air dryer operation
- 28 All lights, interior and exterior
- 29 Headlight beam settings
- **30** Windshield wiper and washer condition, level, and operation
- 31 Passenger door operation and adjustment
- **32** Lavatory operation, toilet flush
- **33** Engine water pump drain hole to be sure it is open (Detroit Diesel)
- 34 Engine Crankshaft vibration damper (Detroit Diesel)
- **35** Throttle control
- **36** Toe adjustment of front wheels
- **37** Drive axle breather for freedom of obstruction
- 38 Air suspension leveling valves for wear and damage
- **39** Emergency window operation
- **40** Voltage regulator brushes
- **41** Air system pressure protection valve settings
- 42 Passenger door locking cams for wear
- 43 Wheel bearings end play
- 44 Wheel brakes: condition of guide pin and tappet bolts
- 45 Wheel brakes: caliper assembly operation
- **46** Wheel brakes: brake pad thickness **47** Wheel brakes: disc run-out
- 48 Propeller shaft
- 49 Exhaust system
- **50** Differential oil

25 Point Checklist

- 1 Engine air intake piping for loose clamps, cracked hoses, etc. (visually)
- 2 Drive belts condition and tension (visually)
- 3 Fluid leaks in engine compartment, wheel hubs etc.
- 4 Tire inflation and condition
- 5 Wheel nuts for tightness
- 6 Wheel rims for cracks and deformation
- 7 Emergency windows for security
- 8 Dashboard gauges and warning lights operation
- 9 Steering ball-joints for excessive play
- 10 Battery cable connections for corrosion and tightness
- 11 Battery electrolyte level
- 12 General condition of the brake assemblies for damage and corrosion
- 13 Brake lining wear
- 14 Shock absorbers for external damage and leakage
- **15** Air dryer operation
- 16 All lights, interior and exterior
- 17 Windshield wiper and washer condition, level, and operation
- **18** Passenger door operation and adjustment
- 19 Emergency window operation
- 20 Voltage regulator brushes
- 21 Wheel bearings end play
- 22 Wheel brakes: condition of guide pin and tappet bolts
- 23 Wheel brakes: caliper assembly operation
- 24 Propeller shaft
- 25 Exhaust system